



COLOR
MorphTM
TECHNOLOGY

72 LED Series,

Colors/Modes:

- | | | |
|----------------------------|-----------------|------------------------------|
| 1. Red | Constant Red | (Synchronized at this Color) |
| 2. Yellow | Constant Yellow | |
| 3. Green | Constant Green | |
| 4. Aqua | Constant Aqua | |
| 5. Blue | Constant Blue | |
| 6. Pink | Constant Purple | |
| 7. White | Constant White | |
| 8. Party Mode | | |
| 9. Color Wheel Mode | | |

Operation:

- **Color Wheel Mode** Smooth color changing patterns.
 - **Party Mode** Random colors and brightness, flashing patterns.
 - **Switch Colors/Modes** To advance to the next color or mode, simply turn "off" the power switch for a minimum of 2 seconds, then turn "on" again.
 - **Synchronize Feature** All 72 Series LED Lights (that are on the same circuit) will stay synchronize together during color/mode selection.
 - **Re-Synchronize the colors** If any of the 72 LED lights (on the same electrical circuit) get out of color/mode sequence, simple turn "off" the power switch for 4 to 5 seconds, then turn "on" again. The 72 Series LED Lights will resynchronize by flashing three times and all the lights in the system will be in the same state thereafter (RED).
 - **Memory – Color/Mode** The 72 Series LED Lights have a memory. When switched "off" for more than 8 seconds, and then turned "on" again, the SpaStar 72 LED lights will return to the same color/mode that they were at, prior to switching "off".
-