

**JEM INDUSTRIES COLOR-CHANGING LED POOL AND SPA LIGHTS
(POOLBRIGHT & SPABRIGHT LIGHTS)**

OPERATING INSTRUCTIONS *

WHEN 2 OR MORE JEM INDUSTRIES COLOR CHANGING POOL OR SPA LIGHTS ARE OPERATED ON THE SAME ELECTRICAL CIRCUIT (ONE SWITCH CONTROLS ALL LIGHTS ON/OFF), THE LIGHTS CAN BE **SYNCHRONIZED TO OPERATE IN THE SAME MODES SIMULTANEOUSLY**—SOLID COLOR OR CHANGING—BY FOLLOWING THESE EASY **DIRECTIONS**:

TURN WALL **SWITCH TO ON**

THEN TURN WALL **SWITCH TO OFF**

WAIT 4 OR 5 SECONDS (SLOW COUNT TO 4 OR 5) BUT **NO LONGER**

TURN WALL **SWITCH TO ON**

ALL LED **LIGHTS WILL FLASH RED 3 TIMES, THEN SHOW SOLID RED** (ALL LIGHTS ARE NOW SYNCHRONIZED)

NOW CONTINUE, WITH A **QUICK WALL SWITCH OFF/ON (ABOUT 2 SECONDS)**, THROUGH EACH OF THE 7 SOLID COLORS. STOP AT ANY COLOR BY LEAVING THE WALL SWITCH ON.

AT THE **8TH OFF/ON**, THE LIGHTS WILL ENTER THE “**PARTY MODE**”—RAPID COLOR CHANGE (STOP AT “PARTY MODE” BY LEAVING WALL SWITCH ON)

AT THE **9TH OFF/ON**, THE LIGHTS WILL ENTER THE “**SLOW CHANGE MODE**”—A GRADUAL MORPHING OF ONE COLOR INTO THE NEXT—NOTE THAT THE “**SLOW CHANGE MODE**” **CAN TAKE A LITTLE TIME PER COLOR, SO BE PATIENT** (STOP AT “SLOW CHANGE” BY LEAVING WALL SWITCH ON).

FINALLY, IF THE WALL SWITCH IS IN THE OFF POSITION FOR MORE THAN 8 SECONDS, THE “MEMORY FEATURE” IN THE LIGHTS’ CIRCUITRY WILL ACTIVATE SO THAT THE NEXT TIME THE WALL SWITCH IS TURNED ON, THE LIGHTS WILL START UP IN THE LAST MODE ACTIVATED BEFORE BEING TURNED OFF.

* THESE LIGHTS ARE INTENDED FOR USE ON ANALOGUE SWITCHES; ELECTRONIC SWITCHES MAY INTERRUPT PROPER OPERATION

***IF LIGHTS GET OUT OF SYNCHRONIZATION, SIMPLY REPEAT THE ABOVE STEPS.

www.bulbwizards.com

1107A-K

PLEASE NOTE:

SPABRIGHT 72 3.20” LIGHTS ARE INDIVIDUALLY MILLED TO SIZE TO ACCOMMODATE SMALLER SIZE SPA LIGHT NICHES.